

K BIKE SWITCH PART NUMBERS

HAZARD WARNING SWITCH	61311459305
Switch - ABS	61311459700
SWITCH PLATE ADJUSTABLE	61312305088
FOG TAIL LAMP SYMBOL	61311459359
SYMBOL HANDLE HEATET	61311459360
Clip without symbol	61311459363
SYMBOL HAZZARD WARNING	61311459367
ANTI BLOCK SYSTEM SYMBOL	61311459703
SYMBOL PLATE ADJUSTABLE	61312305193
FOG TAIL LAMP SYMBOL	61312305197
WINDSCREEN SWITCH	61312305088
WINDSCREEN SYMBOL	61312305193