
A9001 Instrument panel control unit
E9001 Instrument lights
E9010 Headlight
E9011 Low beam headlight
E9012 High beam headlight
E9013 Tail light
E9015 Side light
G9230 Battery
H9010 Lamp indicator lamp
H9012 Telltale light, high-beam headlight
H9050 Brake light
K9120 Load relief relay
S9051 Brake light switch, hand
S9052 Brake light switch, foot
S9060 Ignition switch
S9070 Left multi-function switch
S9071 High beam switch
S9080 Right multi-function switch
S9081 Light switch
X9001 STVB instrument panel control unit
X9013 STVB rear light -
X9014 STVB tail light
X9015 STVB parking light
X9016 STVB parking light
X9053 STVB brake light -
X9054 STVB brake light +
X9230 Battery positive
X9231 Battery ground
X9310 STVB, engine wiring harness
X9340 STVB lighting/rear direction indicator
X9400 Ground I
X9401 Connector 31 I
X9402 Connector 31 II
X9404 Connector 31 IV
X9430 Connector 30U
X9450 Connector 15U
X9451 Connector 15A1
X9451 Connector 15A1
X9480 Connector 15E
X9482 Connector 58