

---

A9001 Instrument panel control unit  
A9190 ABS control unit  
B9193 Wheel-speed sensor, front  
B9194 Wheel-speed sensor, rear  
G9230 Battery  
H9010 Lamp indicator lamp  
H9190 Warning light, ABS  
K9110 Engine-electronics relay  
K9196 ABS relay  
K9197 ABS warning relay  
S9060 Ignition switch  
S9195 ABS button  
X9400 Ground I  
X9401 Connector 31 I  
X9403 Connector 31 III  
X9430 Connector 30U  
X9450 Connector 15U  
X9590 Diagnosis plug