

---

A9001 Instrument panel control unit  
E9001 Instrument lights  
E9010 Headlight  
E9011 Low beam headlight  
E9012 High beam headlight  
E9013 Tail light  
E9015 Side light  
G9230 Battery  
H9010 Lamp indicator lamp  
H9012 Telltale light, high-beam headlight  
H9050 Brake light  
K9110 Engine-electronics relay  
K9120 Load relief relay  
S9051 Brake light switch, hand  
S9052 Brake light switch, foot  
S9060 Ignition switch  
S9070 Left multi-function switch  
S9071 High beam switch  
S9080 Right multi-function switch  
S9081 Light switch  
X9013 STVB rear light -  
X9014 STVB tail light  
X9015 STVB parking light  
X9016 STVB parking light  
X9053 STVB brake light -  
X9054 STVB brake light +  
X9107 DRS, engine electronics/emergency-off relay  
X9107 DRS, engine electronics/emergency-off relay  
X9107 DRS, engine electronics/emergency-off relay  
X9230 Battery positive  
X9231 Battery ground  
X9232 Ground  
X9401 Connector 31 I  
X9402 Connector 31 II  
X9404 Connector 31 IV  
X9451 Connector 15A1  
X9451 Connector 15A1  
X9480 Connector 15E  
X9482 Connector 58  
X9490 Connector 15EL