






This is the way that the pin and the spring are positioned into the horn button




Now, put the switch in a clear plastic bag and pull the rotating part out of it. Springs may fly away!!

9



10



Here is the detailed parts of the high/low beam switch assembly.

These are all the parts that you will get if you dismantle the Hi / Low switch.

If any part is missing, go on your knees and start to hunt for it ;O)

11

