

drawing number: 2305125

A9010 Instrument cluster	2
A9020 Flasher unit	44
A9030 L-Jetronic control unit	79
A9050 Ignition control unit	58
B9000 Fuel gauge	12
B9010 Inductive transmitter	11
B9020 Temperature transmitter	71
B9040 Airflow meter	84
B9050 Magnetic gate	57
E9000 Headlight	20
E9001 Low-beam headlight	19
E9002 High-beam headlight	19
E9010 Headlight	78
E9020 Parking light	24
E9030 Instrument lighting	2
G9000 Battery	66
G9010 Alternator	63
H9000 Battery charge warning light	4
H9010 Oil pressure warning light	4
H9030 Front left flashing turn indicator	4
H9041 Turn indicator repeater, right	4
H9042 Turn indicator repeater, left	4
H9050 Brake light	4
H9060 Neutral telltale	3
H9070 Choke telltale	3
H9080 Fuel level telltale	2
H9090 Bulb telltale	4
H9110 Gear indicator	3
H9200 Brake light	76
H9500 Front left flashing turn indicator	5
H9510 Front right flashing turn indicator	3
H9520 Rear left flashing turn indicator	83
H9530 Rear right flashing turn indicator	83
H9921 Twin-tone horn, left	2
H9922 Twin-tone horn, right	2
K9000 Starter motor relay	54
K9010 Load relief relay	43
K9020 Flasher unit	45
K9030 Horn relay	49
K9040 Injection Relay	45
K9050 Bulb monitoring unit	57
M9000 Starter motor	66
M9010 ### Kraftstoffpumpe ###	12
M9020 ### Lüftermotor ###	22
N9000 Thermostat	55
P9000 Speedometer	2
P9010 Revolution counter	2
S9000 Ignition switch	23
S9100 Combined switch, left	24
S9110 High-beam headlight	21
S9121 Turn indicator switch, left	21
S9130 Horn switch	21
S9220 Turn indicator switch, right	31
S9230 Kill switch	32
S9235 Turn indicator cancel switch	34
S9240 Starter switch	33
S9300 Brake light switch, hand-operated	39
S9310 Brake light switch, foot-operated	63

S9400 Oil pressure switch	11
S9410 Choke switch with telltale lamp	14
S9420 Transmission switch	20
S9430 Clutch switch	41
S9440 Hazard warning flasher switch	46
S9450 Throttle butterfly switch	84
T9010 Ignition coil 1	61
T9020 Ignition coil 2	64
T9030 Ignition coil 3	67
V9000 Clock	3
X9000 Plug connection - engine wiring harness	71
X9010 Plug connection -front indicators	10
X9020 Plug connection - rear section	73
X9030 Plug connection - fairing	10
X9040 Plug connection - oil pressure gauge	12
X9050 Plug connection - special equipment	50
X9060 Plug connection - alarm system	56
X9080 Plug connection - heated handlebar grips	21
X9100 Plug connection - auxiliary instruments	24
X9200 Plug connection - height adjustment	83
Y9001 Valve 1	84
Y9002 Valve 2	84
Y9003 Valve 3	84